

Fuselage Manual TERRIER 200



Drill 12mm hole approx. 12mm from edge.



Position bearing ready to press in.



Put pressure just to outside of bearing.



Drill rim, use brake disc as drill jig, rivet disk to rim.



Mount tire and tube.



Pressure 15 lbs.

© Copyright Foxcon Aviation Mackay

Fuselage Manual TERRIER 200	No: 991040
	Rev: 7/ 00
	Page: 8 of
FoxCon Aviation Mackay, QLD.	