

Fuselage Manual TERRIER 200



Use pivot # 2-5006.

Drill a 5/16" hole about 50 mm from leg end. Bolt mounted upright gets the fairing on easier.



Slide the fork # 2- 5014 on and get the washer and nut installed from the bottom.



Get axle # 2-5015, spacer # 2-5021/22 ready to go to the front wheel.



Get the wheel installed.



Slot the front wheel fairing, make a flange, use speednuts and screws the get to cut out piece attached the the fairing.



Use 2 1/4" bolts each side to mount the fairing.

© Copyright Foxcon Aviation Mackay

Fuselage Manual TERRIER 200	No: 991040
	Rev: 7/ 00
FoxCon Aviation Mackay, QLD.	Page: 9 of