

# Wing Manual TERRIER 200



This is a good position to glass the main spar in.



Use a tube or broomstick and wrap it with packing tape and put brush on a long handle.



Make special tools at least 2100mm long for that delicate job.



Place the bi directional glass strip on top



Put the wet glass strip in position.



Place it equally in the corner between main spar and top wing. Use the long brush to make it smooth. Repeat from the other side.

© Copyright Foxcon Aviation Mackay

Wing Manual TERRIER 200

No: 022006

Rev: 12 / 02

FoxCon Aviation Mackay, QLD.

Page: 6 of